


HUMIDITY / TEMPERATURE TRANSMITTER **TRH-300 series**

ORDERING INFORMATION

MODEL NO.	DESCRIPTIONS	
TRH-301	Temperature Transmitter	
TRH-302	Humidity Transmitter	
TRH-303	Humidity / Temperature Transmitter	
SHAPE (Mounting)	W	Wall mount Type
	D	Duct mount type
	S	Sensor separated Type
Output	A	Current output
	V	Voltage output

Example: **TRH-303WA** Humidity and Temperature transmitter, wall mount type, With current output.

ON-SITE CALIBRATION & WIRING



Humidity Calibration:


VR 1ZERO Humidity
 VR 2SPAN Humidity

Temperature Calibration:


VR 3ZERO Temperature
 VR 4SPAN Temperature

EXTERNAL DIMENSIONS (mm)

Wall mount type




Duct mount type



CONNECTING DIAGRAM

TRH-300A Current output type



TRH-300V Voltage output type

